



MOTION PRO, INC.  
3171 Swetzer Road  
Loomis, CA 95650  
Tel 650.594.9600 Fax 650.594.9610  
www.motionpro.com


# INSTRUCTIONS

## REAR BRAKE KIT P/N # 01-0298 & 01-0299 (YFS 200 BLASTER)

**IMPORTANT - READ BEFORE INSTALLING**  
**WE RECOMMEND THAT THIS KIT BE INSTALLED BY A QUALIFIED MECHANIC IN A PROPERLY EQUIPPED SHOP.**

**THESE INSTRUCTIONS ARE FOR USE WITH THE REAR BRAKE KIT LISTED ABOVE. THIS KIT IS DESIGNED TO REPLACE THE ORIGINAL HAND/FOOT BRAKE CABLE WITH A FOOT ONLY BRAKE CABLE.**

1. Remove the brake cable from the handlebar lever assembly.
2. Pull back the cable adjuster cover boot from the rear brake caliper. Loosen the lock nut until it stops. Turn the adjuster clockwise until it stops. Remove the three 6mm socket head bolts on the caliper cover. Remove the gasket. Use care not to change the adjustment on the ratchet assembly.
3. Remove the brake cable from the caliper body and replace with your new Motion Pro cable. Use new gasket and install the caliper cover and then torque socket head bolts to 9 foot pounds.
4. Route the cable to the rear pedal and hook up eyelet on brake pedal. Use the shoulder pin kit #01-0027 and adjust cable to the caliper.
5. To check brake: block the rear of the machine off the ground and spin the rear wheel. To insure that the brake works also check for brake drag. If any brake drag is noticed, perform the needed adjustment.



### TO ADJUST INTERNAL CALIPER RATCHET

1. Pull ratchet toward yourself about 5mm, making sure that the ratchet is not in contact with the stopper spring. Tighten the adjust bolt by turning the ratchet counterclockwise. Push the ratchet back in place and make sure that it is in contact with the stopper spring.