



Motion Pro, Inc.
867 American Street
San Carlos, CA 94070
Tel: 6550-594-9600 Fax: 650-594-9610
www.motionpro.com

INSTRUCTIONS

FOR INSTALLING T3 CABLES

T3 Slidelight Clutch/Hot Start and T3 Throttle Cables should be installed by a professional mechanic in accordance with your vehicle's factory shop manual and specifications.

Warning: Improper installation could result in great bodily injury or death.

Important: These cables have been prelubed at the factory. No additional lube is necessary before installation. Lube cables periodically while in use. We recommend using Motion Pro Cable Lube (part# 15-0002).